

Helical Rod Spacer

Weight: 0.00kg

Dimensions: 0.00cm x 0.00cm x 0.00cm

Description

The **HELICAL ROD Spacer** is recommended for use on horizontal, twin conductor bundles.

The functions of the HELICAL ROD Spacer are:

- To provide uniform spacing of horizontally bundled subconductors
- To insure consistent electrical characteristics
- To minimize wind induced motions such as subconductor oscillation and aeolian vibration so that no conductor damage results
- To keep the subconductors from entangling due to galloping, ice unloading, and fault currents.